

# Air Runner Blocks

Runners are used on running backstays of offshore boats to adjust mast bend for different wind conditions.

Integrated sideplate bails and recessed cotter key help produce a smooth design that won't snag lifelines.

Foam padded Block Socks easily install over Air Runner blocks to protect your blocks, deck, and crew.

About Black Magic Air blocks: see feature pages at beginning of this section.



*Sideload bearing strips dampen rig vibration.*



3224  
3238  
3251  
3259  
3264



3239  
3252  
3260  
3265



3035  
3036  
3037  
3038

## Block Socks

Block Socks	
Part No.	Fits
3035	3224/3238/3239
3036	3251/3252
3037	3259/3260
3038	3264/3265

## Runner Blocks

Part No.	Description	Sheave Ø		Length		Weight		Clevis pin Ø		Max Line Ø		Maximum working load		Breaking load	
		in	mm	in	mm	oz	g	in	mm	in	mm	lb	kg	lb	kg
<b>57 mm</b>															
3224	Single	2 1/4	57	3 3/8	86	4.42	125	3/8	10	1/2	12	2500	1134	5000	2268
<b>75 mm</b>															
3238	Single	3	75	4 5/8	118	10.16	288	1/2	12.7	9/16	14	5000	2268	10000	4544
3239	Single/becket	3	75	5 1/4	146	11.2	318	1/2	12.7	9/16	14	5000	2268	10000	4544
<b>100 mm</b>															
3251	Single	4	100	6 3/16	157	17	481	5/8	15.9	5/8	16	7500	3402	15000	6802
3252	Single/becket	4	100	7 9/16	193	19.12	542	5/8	15.9	5/8	16	7500	3402	15000	6802
<b>125 mm</b>															
3259	Single	5	125	7 11/16	195	29.76	844	3/4	19	3/4	19	11000	4990	22000	9980
3260	Single/becket	5	125	9 1/2	240	33.52	950	3/4	19	3/4	19	11000	4990	22000	9980
<b>150 mm</b>															
3264	Single	6	150	8 3/4	221	50.64	1436	3/4	19	1	25	15000	6802	30000	13605
3265	Single/becket	6	150	10 3/16	275	56.72	1608	3/4	19	1	25	15000	6802	30000	13605

# Crossover Blocks

Crossover blocks provide a cleaner, more efficient deck. These easy-to-install blocks mount behind the stopper bank on each side of the cabin house and can route any line to the winch on the opposite side. Blocks feature built-in risers and sculpted backing plates. The large, strong bases protect cored decks. Use the 1984 for boats to 11.5 m (38') and the 1981 for boats to 15 m (48').



1984  
1981

Part No.	Description	Sheave Ø		Base Ø		Height		Weight		Max line Ø		Maximum working load		Breaking load	
		in	mm	in	mm	in	mm	oz	g	in	mm	lb	kg	lb	kg
1984	Crossover	1 3/4	44	2 1/16	52	1 1/4	32	4.2	119	3/8	10	2000	907	4000	1814
1981	Crossover	2 3/16	56	2 5/8	66	1 7/16	36	8	227	7/16	12	3000	1361	6000	2721

Fastener included.